

POPWHITENER BL

APPLICATION METHODS :

1. For white & Pale colour Leathers : - (% age on shaved wt.)
(Before rechroming)

Water	200 %
Popwhitener BL	1.0 to 2.0 % 30 min.
Sodium Bisulphite	1.0 to 2.0 % 30 min.
Oxalic Acid	0.5 to 1.0 % 20 min. check D/wash thoroughly

- 2) For vegetable tanned leather having deep black Iron Stains. (% age on shaved wt. before dyeing).

Water 40 ° C	200 %
Popwhitener BL	2.0 to 3.0 % 30 min.
Sodium MetaBisulphite (NA ₂ S ₂ O ₅)	0 to 3.0% 30 min.
Oxalic Acid)	1.0 to 1.5% 30 min. check D/wash thoroughly.

- 3) Decolourisation of dyed Leathers. (%age on shaved wt.)

Water	200%
Non Ionic detergent	0.5%
Liquor Ammonia	1.0 % 45 min. check pH 4.5/4.6 D/wash.

Water 60 to 70 ° C	300 %
Popwhitener BL	2.0 to 5.0 % 2 Hours
Sodium MetaBisulphite(NA ₂ S ₂ O ₅)	1.0 to 2.0 % 30 min. (check D/Wash thoroughly)

Note : - % age of Popwhitener BL depends upon the depth of the shade of leather or the % age of dye amount used.

CAUTIONS :

1. Keep in a cool & dry place.
2. Don't expose to air. Keep air tight.
3. Keep away from water contact.
4. Avoid using Iron Bamboo.

